



108.04A

PREPRITE® PROBLOCK®

Interior/Exterior Latex Primer/Sealer B51-600 Series

As of 08/01/2013, Complies with:			
OTC	Yes	LEED® 09 CI	Yes
SCAQMD	Yes	LEED® 09 NC	Yes
CARB	Yes	LEED® 09 CS	Yes
CARB SCM 2007	Yes	LEED® H	Yes
MPI #	3,6,17,39	NGBC	Yes

CHARACTERISTICS

- Assures uniform appearance of topcoats
- Fast dry
- Apply at temperatures down to 35°F
- Assures adhesion of the topcoat to slick, glossy surfaces
- Seals out solvent sensitive stains - tar, solvent based markers, etc.
- Seals minor dried water stains and tannin
- Provides easy "slip" for positioning of wallpaper
- **Anti-microbial** - This product contains agents which inhibit the growth of microbes on the surface of this paint film.

Use on interior:

- Ceiling Tiles
- Paneling
- Wall Laminate
- Cured Plaster
- Drywall
- Varnished Woodwork
- Kitchen Cabinets
- Ceramic Wall Tile
- Under wallcovering

Use on interior & exterior:

- Wood
- Aluminum
- Galvanized Metal
- Previously Painted Surfaces
- PVC Piping
- Concrete and Masonry
- Many Plastics
- Glossy Surfaces
- Fiberglass
- Copper
- Glazed Block

CHARACTERISTICS

Color: White & Deep Base
Coverage: 400 sq ft/gal @ 4 mils wet; 1.4 mils dry

Drying Time, @ 77°F, 50% RH:
 Touch: 30 minutes
 Recoat as a primer: 1 hour
 Recoat as a stain sealer: 4 hours
 To apply wallcovering: 3 hours

Drying and recoat times are temperature, humidity and film thickness dependent.

Flash Point: N/A

Finish: 3-13 units @ 85°

Tinting: requires ColorCast Ecotoners

Base	oz/gal	Strength
White	0 - 4	100%
Deep Base	4-12	100%

Vehicle Type: Styrenated Acrylic Latex B51W00620

VOC (less exempt solvents): <50 g/L; <0.42 lb/gal
 As per 40 CFR 59.406 and SOR/2009-264, s.12

Volume Solids: 35 ± 2%

Weight Solids: 52 ± 2%

Weight per Gallon: 10.9 lb

For best topcoat color development, use the recommended "P"-shade primer. If desired, up to 4 oz per gallon of Color-Cast Ecotoners can be used to approximate the topcoat color. Check color before use.

When spot priming on some surfaces, a non-uniform appearance of the final coat may result, due to differences in holdout between primed and unprimed areas. To avoid this, prime the entire surface rather than spot priming.

For optimal performance, this primer must be topcoated with a latex, alkyd/oil, water based epoxy, or solvent based epoxy coating on architectural applications.

For exterior exposure, this primer must be topcoated within 14 days with architectural latex or oil finishes.

For better performance when priming an entire house, use Exterior Latex or Oil-Based Primers

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.

Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull.

Special recommendations - After priming stained areas, allow to dry 4 hours, test a small area for bleeding by applying the topcoat before painting the entire project. If the stain bleeds through, apply a second coat of primer and allow to dry overnight and retest before topcoating.

Fire restoration work - Thoroughly clean the surface before applying to smoke stained areas. Apply one or two coats of PrepRite ProBlock Latex Primer/Sealer and test a small area for bleeding before painting the entire surface.

Always check for compatibility and adhesion to the surface by applying a test patch of 2 - 3 square feet. Allow to dry thoroughly for 1 week before checking adhesion.



**SHERWIN
WILLIAMS.**

PREPRITE[®] PROBLOCK[®]

Interior/Exterior Latex Primer/Sealer B51-600 Series

SURFACE PREPARATION

General Priming - PrepRite ProBlock Latex Primer/Sealer can be topcoated in 1 hour in non-stain blocking applications.

Plaster - Must be cured, usually 30 days, and hard. If painting cannot wait, allow the surface to dry 7 days and prime with Loxon Concrete and Masonry Primer. Soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with water and allow to dry before painting.

Wood - Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth.

Tile, laminate, ceramic and plastic tiles, and similar glossy surfaces, must be free of all oil, grease, and soap residue. Do not use this product in areas subject to excessive water, e.g.: in showers, around sinks, on counter tops.

Testing - On hard, slick, glossy, or otherwise hard to paint surfaces, after preparing the surface, apply a test area of this primer, allow to dry properly and test for adhesion.

Caulking - Fill gaps between walls, ceilings, crown moldings, and other trim with the appropriate caulk after priming the surface.

SURFACE PREPARATION

Mildew - Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the surface for 10 minutes. Rinse thoroughly with water and allow the surface to dry before painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any of the mixture that comes in contact with your skin. **DO NOT ADD DETERGENTS OR AMMONIA TO THE BLEACH/WATER SOLUTION.**

APPLICATION

When the air temperature is at 35°F, substrates may be colder; prior to painting, check to be sure the air, surface, and material temperature are above 35°F and at least 5°F above the dew point. Avoid using if rain or snow is expected within 2-3 hours. Air and surface temperatures must not drop below 35°F for 48 hours after application.

Do not reduce for stain blocking.

No reduction necessary.

Brush - Use a nylon/polyester brush.

Roller - Use a 3/8" nap soft woven roller cover.

Spray—Airless

Pressure..... 2000 psi

Tip..... .015"-.021"

CLEANUP INFORMATION

Clean spills, spatters, hands and tools with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral spirits.

CAUTIONS

Protect from freezing.

LABEL CAUTIONS

Use only with adequate ventilation. To avoid overexposure, open windows and doors or use other means to ensure fresh air entry during application and drying. If you experience eye watering, headaches, or dizziness, increase fresh air, or wear respiratory protection (NIOSH approved) or leave the area. Avoid contact with eyes and skin. Wash hands after using. Keep container closed when not in use. Do not transfer contents to other containers for storage. **FIRST AID:** In case of eye contact, flush thoroughly with large amounts of water. Get medical attention if irritation persists. If swallowed, call Poison Control Center, hospital emergency room, or physician immediately. **WARNING:** This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. **DO NOT TAKE INTERNALLY. KEEP OUT OF THE REACH OF CHILDREN.**

HOTW 04/01/2013 B51W00620 09 00

The information and recommendations set forth in this Product Data Sheet are based upon tests conducted by or on behalf of The Sherwin-Williams Company. Such information and recommendations set forth herein are subject to change and pertain to the product offered at the time of publication. Consult your Sherwin-Williams representative to obtain the most recent Product Data Sheet.