

ROCKLATH® Brand Plaster Base

FIRECODE® C Core

Preparation

Assure that all framing is sound and free of warps and twists.

Installation

Apply ROCKLATH Brand FIRECODE C Core Plaster Base face out with long dimension across supports and with end joints staggered between courses. Cut lath accurately so that it slips easily into place without forcing, and fits neatly around electrical outlets, openings, etc. Install any lengthwise raw-cut edges at bottom strip or wall-ceiling angle. Nail, screw or staple to wood studs; screw attach to steel studs or furring channels. Support butt joints between framing members with B-1 bridge clips. Apply Cornerite metal lath to corners and staple attach.

Trademarks

The following trademarks used herein are owned by United States Gypsum or a related company: FIRECODE and ROCKLATH.

Note

Products described here may not be available in all geographic markets. Consult your U.S. Gypsum Company sales office or representative for information.

Notice

We shall not be liable for incidental or consequential damages, directly or indirectly sustained, nor for any loss caused by application of these goods not in accordance with current printed instructions or for other than their intended use. Our liability is expressly limited to replacement of defective goods. Any claim shall be deemed waived unless made in writing to us within thirty (30) days from the date it was or reasonably should have been discovered.

SAFETY FIRST!

Follow good safety practices. Read material safety data sheets and related literature on products before specification and/or installation.

