

BUR DEFECT	OPTIONS	REINFORCEMENT	REPAIR MASTIC or SEALANT
Split, Laps & Seams	Preferred Repair:	483 Poly (Layers equal to Existing) or Fleece-Top Tape	264, 505, 581
	Basic Repair:	483 Poly or 470 Cotton	115, 122, 128, 133, 365
Blisters	Preferred Repair:	483 Poly (Layers equal to Existing) or Fleece-Top Tape	264, 505, 581
	Basic Repair:	483 Poly or 470 Cotton	115, 122, 128, 133, 365
Ridges & Wrinkles	Preferred Repair:	483 Poly (Layers equal to Existing) or Fleece-Top Tape	264, 505, 581
	Basic Repair:	483 Poly or 470 Cotton	115, 122, 128, 133, 365
Flashing	Preferred Repair:	483 Poly (Layers equal to Existing) or Fleece-Top Tape	264, 505, 581
	Basic Repair:	483 Poly or 470 Cotton	115, 122, 128, 133, 365
Term Bar	Preferred Repair:	Fleece-Top Tape	AP-1
	Basic Repair:	n/a	AP-1
MOD-BIT DEFECT	OPTIONS	REINFORCEMENT	REPAIR MASTIC or SEALANT
Split, Laps & Seams	Preferred Repair:	483 Poly (Layers equal to Existing) or Fleece-Top Tape	264, 505, 581
	Basic Repair:	483 Poly or 470 Cotton	115, 133, 365
Blisters	Preferred Repair:	483 Poly (Layers equal to Existing) or Fleece-Top Tape	264, 505, 581
	Basic Repair:	483 Poly or 470 Cotton	115, 133, 365
Ridges & Wrinkles	Preferred Repair:	483 Poly (Layers equal to Existing) or Fleece-Top Tape	264, 505, 581
	Basic Repair:	483 Poly or 470 Cotton	115, 133, 365
Flashing	Preferred Repair:	483 Poly (Layers equal to Existing) or Fleece-Top Tape	264, 505, 581
	Basic Repair:	483 Poly or 470 Cotton	115, 133, 365
Term Bar	Preferred Repair:	Fleece-Top Tape	AP-1
	Basic Repair:	n/a	AP-1
SINGLE-PLY DEFECT	OPTIONS	REINFORCEMENT	REPAIR MASTIC or SEALANT
Split, Laps & Seams	Preferred Repair:	Fleece-Top Tape	264, 581
	Basic Repair:	483 Poly	264*, 581, 585
Punctures & Tears	Preferred Repair:	Fleece-Top Tape	264, 581
	Basic Repair:	483 Poly	264*, 581, 585
Flashings, Exposed Scrim	Preferred Repair:	Fleece-Top Tape	264, 581
	Basic Repair:	483 Poly	264*, 581, 585
Shrinkage	Basic Repair:	n/a	CUT, SPLICE, WIRE BRUSH & PRIME, 296
METAL DEFECT	OPTIONS	REINFORCEMENT	REPAIR MASTIC or SEALANT
Exposed Fasteners	Preferred Repair:	None	264, 581
Vertical Seams	Preferred Repair:	Fleece-Top Tape	264, 581
	Basic Repair:	483 Poly	264, 581
Flashings	Preferred Repair:	Fleece-Top Tape	264, 581
	Basic Repair:	483 Poly	264, 581
Horizontal Seams	Basic Repair:	None	2210 Butyl (between seams)

Successful Repairs start with proper preparation and planning:

1. Always clean substrate.
2. Use an all weather product as conditions require. If possible, dry substrate prior to application to avoid trapping moisture.
3. Where applicable, use appropriate primer.
4. Repair leaks and defects with mastics and reinforcements (coatings alone do not qualify as a waterproofing membrane).
5. All repairs must be coated or granulated to match existing roof.
6. *When using items with an asterisk "*" on Single Ply applications, complete a peel adhesion test or use 296 primer prior to application.

For technical support and specs contact your local APOC representative.