

MIXING & APPLICATION SEQUENCE

VAPORTIGHT COAT®-SG2 is supplied in a 2.1 gal kit



1. Cut plastic seal and remove safety metal ring.



2. Pierce a hole through the top (rubber membrane) and the bottom of Part B.



3. Completely drain Part B (hardener) into Part A (resin).



4. Mix for approx. 5 minutes. Use complete kit in the proportions supplied. (Do not alter proportions.)



5. Pour mixed material into a clean container.



6. Carefully mix once more for approx. 30 seconds.



7. Pour appropriate amount of material onto slab and spread evenly with a roller or squeegee.



8. Carefully scrub SG2 into the pores with a long handled broom or scrub brush.



9. Follow with a roller to achieve a uniform coverage.



10. Immediately broadcast sand to rejection (full broadcast) on top of fresh SG2.