

BRICKFORM® SM Professional Grade™



Sample Kit Instructions

The SM Professional Grade sample kit is an easy to use package of materials designed to help applicators create customer samples or for learning new techniques in texturing or coloring. The kit provides all materials for base coating and texture coating for approximately 16 square feet.

Pack Includes:

Two ... 5 lb buckets of SM Professional Grade
One ... 35 oz bottle of Liquid Polymer
Two ... 2 oz bottles of Overlay Liquid Colorant
One ... 16 oz bottle of Brickform Triple Seven Bond Coat Primer

Directions:

First apply the base coat (SM Professional Grade) over a primed surface using the 16 oz of BRICKFORM Triple Seven Bond Coat primer, provided in the kit. Apply Triple Seven Bond Coat Primer with a roller or sprayer. Apply evenly over entire surface. Be sure to apply the base coat within two hours of applying the Bond Coat.

Second, mix the base coat:

Measure out 19oz of Liquid Polymer and pour into a mixing bucket. Add one bottle of the Overlay Liquid Colorant to the Liquid Polymer. Make sure to get all the pigment out of the small bottle by adding some polymer and shaking the bottle. Now take one of the buckets with 5 lbs of SM Professional Grade and add to the 19 oz of polymer and mix until uniformly blended and lump free. Allow the mixed material to stand for approximately 10 minutes and re-mix for 90 seconds prior to placement. Apply base coat with a soft rubber squeegee or steel trowel.

Allow the base coat to dry at least two hours or more depending on ambient conditions. Once dry, the base coat can be sanded with a 60-80 grit sanding disc on a floor machine or a mason rub brick. Remove all residues from the sanding process.

Spray Coat / Texture Coat:

Measure out 16 oz of Liquid Polymer and pour into a mixing bucket. Add one bottle of the Overlay Liquid Colorant to the Liquid Polymer. Make sure to get all the pigment out of the small bottle by adding some polymer and shaking the bottle. Now take one of the buckets with 5 lbs of SM Professional Grade and add to the 19 oz of polymer and mix until uniformly blended and lump free. Allow the mixed material to stand for approximately 10 minutes and re-mix for 90 seconds prior to placement. Apply texture coat with a trowel or a hopper gun (texture type spray gun). If troweling, apply at thicknesses of less than 1/8". Sprayed texture can be "knocked down" by using a pool trowel if desired.