



WALL SUBSTRATE

CCW CONTACT ADHESIVE

FACTORY EDGE

SEE T  
JOINT  
DETAIL

NOTES:

1. START AT TOP, ADHERE TOP OF SHEET AND UNROLL DOWN WALL
2. OFFSET HORIZONTAL SEAMS 12" MINIMUM
3. LAP NEIGHBORING PIECES AT LEAST 2"

FIELD CUT EDGE

APPLY CCW-LM-800XL OR  
705-1 APPROVED SEALANT  
OVER FIELD CUT EDGES

12" MINIMUM

DETAIL IS INTENDED TO BE A GUIDE  
FOR AIR BARRIER INSTALLATION ONLY.

705-2B

CCW-705  
VERTICAL INSTALLATION



© 2012 CARLISLE CORPORATION