



- NOTES:**
1. IF VERTICAL SPLICE IS NOT LOCATED AT CORNER, 6" (15.5cm) WIDE UNCURED ELASTOFORM FLASHING OR PRESSURE-SENSITIVE FLASHING MUST BE CENTERED OVER FIELD SPLICE AT ANGLE CHANGE.

* FOR PROPER IN-SEAM SEALANT PLACEMENT REFER TO DETAIL U-2-A

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

860P-5A

EXPOSED CURB FLASHING



© 2012 CARLISLE CORPORATION