



NOTES:

1. APPLY CCW-525 MEMBRANE AT 60 MILS THICK. ALLOW TO CURE 24 HOURS.
2. INSTALL CCW PROTECTION BOARD OR CCW MIRADRAIN DRAINAGE COMPOSITE.

DETAIL IS INTENDED TO BE A GUIDE FOR WATERPROOFING INSTALLATION ONLY.

525-10C

PAVERS ON PEDESTALS
PLAZA DECK



© 2012 CARLISLE CORPORATION