



INSULATION

INTERIOR SHEATHING

FILL ALL GAPS BETWEEN INSULATION BOARDS: APPLY BEAD OF FOAM SEALANT, OR BUTTER EDGE OF BOARD WITH CCW-LM-800XL AND STRIKE FLUSH

STEEL OR WOOD STUDS

INSULFOAM EPS- OR OTHER INSULATION APPROVED FOR BELOW GRADE

APPROVED SEALANT OR FOAM SEALANT

SURE-SEAL TERM BAR W/ APPROVED SEALANT/ MASTIC FOR USE WITH TWF

EXTERIOR CLADDING (REF SH-0D)

R2+ SHEATHE

FULLY ADHERED THROUGH WALL FLASHING

WASHER WITH FASTENER (REF SH-0A)

4" MINIMUM CCW-FOIL-GRIP 1402

CAVITY FULLY GROUTED

GRADE

CARLISLE WATERPROOFING OR APPROVED SYSTEM BY OTHERS

3" MIN.

DETAIL IS INTENDED TO BE A GUIDE FOR INSULATION INSTALLATION ONLY. WALL ASSEMBLY SHOWN COVERS A BROAD RANGE OF CONSTRUCTION TYPES. FOR R2+ WALL ASSEMBLIES MEETING NFPA 285, CONSULT DRAWINGS SH-0D.

SH-7

POLYISO INSULATION FOUNDATION TIE-IN



© 2013 CARLISLE CORPORATION