



NOTES:

1. STOP CCW 300HV PROTECTION FABRIC MAT AT BASE OF DRAIN.
2. ALL BOLTS OR CLAMPS MUST BE IN PLACE TO PROVIDE CONSTANT COMPRESSION ON WATER CUT-OFF MASTIC.
3. CUT THE MEMBRANE SO IT EXTENDS A MIN. OF 1/2" (13mm) FROM THE ATTACHMENT POINTS OF THE DRAIN CLAMPING RING.
4. HOLE IN MEMBRANE MUST EXCEED THE SIZE OF DRAIN PIPE.
5. ROOF DRAIN SIZE AND NUMBER OF DRAINS SHALL BE IN ACCORDANCE WITH APPLICABLE LOCAL CODES.
6. REMOVE ALL LEAD AND OTHER FLASHING, WHERE EXISTING DRAINS ARE FLASHED.

20100420



HYDROPACK® ROOF DRAIN

DETAIL(S) NOT TO SCALE
JULY 26, 2011

© 2010 Carlisle SynTec a division of Carlisle Construction Materials Incorporated



GREEN GRID SYSTEM
HP

SHEET NO.
4