



NOTES:

1. STOP CCW 200V PROTECTION FABRIC MAT BASE OF DRAIN.
2. ALL BOLTS OR CLAMPS MUST BE IN PLACE TO PROVIDE CONSTANT COMPRESSION ON WATER CUT-OFF MASTIC.
3. CUT THE MEMBRANE SO IT EXTENDS A MIN. OF 1/2" (13mm) FROM THE ATTACHMENT POINTS OF THE DRAIN CLAMPING RING.
4. HOLE IN MEMBRANE MUST EXCEED THE SIZE OF DRAIN PIPE.
5. ROOF DRAIN SIZE AND NUMBER OF DRAINS SHALL BE IN ACCORDANCE WITH APPLICABLE LOCAL CODES.
6. REMOVE ALL LEAD AND OTHER FLASHING, WHERE EXISTING DRAINS ARE FLASHED.