

- **INSTALLATION REQUIREMENTS**

- To insure the installation of all Linesets products is performed correctly, please adhere to these required industry installation practices. This includes our standard elastomeric insulation and Black Shield Insulation.

- **LINESET SEALING:**

- To minimize heat loss and control condensation, proper sealing of the line set insulation during the installation process in accordance with ASTM C1710 is mandatory.
- It is especially important to seal the end of pipe run to prevent ambient air from entering the system. Failure to do so could result in condensation formation between the insulation and pipe.
- cerroset advises using Armacell 520 adhesive.

