


AquaBead®

DRYWALL CORNER



Easy-to-apply, Water-activated,
Self-adhesive,
Drywall Corner



Water-activated AquaBead® offers fast, easy installation and outstanding performance, every time.

- Spray on water, wait 20 - 30 seconds and press—no compound or adhesive required
- Can be coated in 30 minutes for quicker finishing
- Superior Bond—water-activated adhesive creates an exceptional bond to drywall
- Perforations allow compound to adhere to the drywall surface
- Robust paper-plastic-paper design withstands impacts and movement to prevent dents and edge cracking

PRODUCT DATA

PRODUCT	CERTAINTEED CODE	PACKAGE SIZE
AquaBead Outside 90° - 8'	639662	50 Sticks / Carton
AquaBead Outside 90° - 9'	639661	50 Sticks / Carton
AquaBead Outside 90° - 10'	639663	50 Sticks / Carton
AquaBead Outside 90° - 12**	639717	50 Sticks / Carton
AquaBead Bullnose - 8'	639666	50 Sticks / Carton
AquaBead Bullnose - 9'	639665	50 Sticks / Carton
AquaBead Bullnose - 10'	639660	50 Sticks / Carton
AquaBead L-Trim 1/2" - 10'	639664	50 Sticks / Carton
AquaBead L-Trim 5/8" - 10'	639872	50 Sticks / Carton
AquaBead Outside 90° Trim - 8'	640742	50 Sticks / Carton
AquaBead Outside 90° Trim - 9'	640743	50 Sticks / Carton
AquaBead Outside 90° Trim - 10'	640744	50 Sticks / Carton
AquaBead Outside 90° Trim - 12'	640745	50 Sticks / Carton

Custom lengths may be available on special order.
Consult your CertainTeed sales representative.

CertainTeed
SAINT-GOBAIN

AquaBead®

INSTALLATION INSTRUCTIONS

OUTSIDE 90

When installing drywall for 90° corners, hang Outside 90 as shown in Figure 1a. Ensure that the drywall at the corner does not overlap the joint compound as shown in Figure 1b.

Figure 1a





Figure 1b



BULLNOSE

When installing drywall for Bullnose corners, hang as shown in Figure 2a and 2b. Ensure that drywall at the corners do not touch creating an open area for the radius of the bead.

Figure 2a





Figure 2b



PREPARATION

- AquaBead can be cut to length using scissors, metal snips or a chop saw.

TIP: Save time by using a chop saw to cut multiple pieces of AquaBead to the same length.

- Using a spray bottle or pump sprayer, completely wet the adhesive side of the AquaBead® with clean, ordinary tap water.

IMPORTANT: Do not use a sponge to apply water as it will remove adhesive. Add a bit of food coloring to the water to make it easier to see where you have sprayed.

TIP: Add a bit of food coloring to the water to make it easier to see where you have sprayed.

- If you apply less water the working time is decreased, but the tack (stickiness) is increased. To extend working time add more water.
- After applying water, allow 20 - 30 seconds for the AquaBead to activate. Temperature and humidity may affect drying times.
- Make sure the entire adhesive surface on the back of AquaBead is wet before application.

APPLICATION

- Place the wet, adhesive side of the AquaBead on the wall corner, aligning it tightly to the ceiling. The beaded edge of the AquaBead should be squared with the centre of the corner. Make sure it is straight.
- Press the AquaBead firmly by hand or with a roller, making sure the flanges contact the drywall surface completely.
- **REPOSITIONING:** AquaBead can be removed, re-wetted and repositioned if the adhesive has not set.

- AquaBead adhesive will not stick to previously finished drywall surfaces. Use a spray adhesive or joint compound to adhere to previously finished surfaces.
- If an area has not properly bonded, it can be mechanically fastened with staples before coating.

IMPORTANT: Once the adhesive has set, the AquaBead will be permanently bonded to the drywall and cannot be repositioned.

TIP: If you have exposed drywall edges, use L-Trim for a quick and clean finish.

- If preferred, Taping or Mid to Heavy-weight All Purpose Joint Compounds can be used to adhere AquaBead. If using this method, ensure joint compound has thoroughly dried before applying a fill coat.

TIP: Create a guide with a pencil or chalk line to get straight corners, especially on bulkheads and long runs.

FINISHING

- AquaBead corner can be filled after 30 minutes using All-Purpose or Finishing joint compound.
- Apply joint compound over the AquaBead using an 8" - 10" taping knife, filling the holes. Allow compound to dry thoroughly.
- Skim over the AquaBead corner once more with joint compound using a 10"-12" finishing knife. Let dry, then sand and paint.

Shipped in water-resistant packaging. Store in a dry location. Protect from moisture.

USGBC® and the related logo are trademarks owned by the U.S. Green Building Council® and are used with permission.



The Health Product Declaration® logo is a trademark or service mark of Health Product Declaration Collaborative, Inc., in the United States and in other countries and is being used herein under license.



CertainTeed

CEILING • DECKING • FENCE • GYPSUM • INSULATION • RAILING • ROOFING • SIDING • TRIM
20 Moores Road, Malvern, PA 19355 800-233-8990 certainteed.com