

Subject:	Maintenance Instructions for CertainTeed textured mineral fiber panels (Cashmere, Cashmere Customline, Cashmere High NRC, Cashmere Style Edge, Sand Micro, Sand Micro Customline)		
Date:	June 12, 2025	Tel:	800-233-8990
Email:	Robert.L.Marshall@saint-gobain.com Thomas.Callahan@saint-gobain.com		

Handling

Clean cotton gloves should be worn at all times, both during the initial ceiling assembly and any subsequent activity that may require a panel to be removed. When panels are removed they should be taken completely out of the grid and stored on a flat surface. Panels should be laid face to face in order to prevent unnecessary soiling and damage during their temporary displacement.

Cleaning

Panels can be cleaned of dust and loose dirt particles by vacuuming with a soft brush attachment.

If any portion of this information provokes a question, please do not hesitate to contact CertainTeed Technical Services.