

Subject:	Maintenance Instructions for <b>CertainTeed</b> textured mineral fiber panels (Cashmere, Cashmere Customline, Cashmere High NRC, Cashmere Style Edge, Sand Micro, Sand Micro		
	Customline)		
Date:	June 12, 2025	Tel:	800-233-8990
Email:	Robert.L.Marshall@saint-gobain.com		

## Handling

Clean cotton gloves should be worn at all times, both during the initial ceiling assembly and any subsequent activity that may require a panel to be removed. When panels are removed they should be taken completely out of the grid and stored on a flat surface. Panels should be laid face to face in order to prevent unnecessary soiling and damage during their temporary displacement.

## **Cleaning**

Panels can be cleaned of dust and loose dirt particles by vacuuming with a soft brush attachment.

If any portion of this information provokes a question, please do not hesitate to contact CertainTeed Technical Services.

