

CHEMSTOP WB REGULAR

Water Based Silane/Siloxane Penetrating Water Repellent Sealer for Porous Masonry and Concrete Surfaces.

Note: The paragraphs below are meant to be incorporated into Parts 2 and 3 of a standard CSI 3 Part Format specification, the General Structural Notes, or directly onto the plans. They must be carefully reviewed by a qualified design professional and edited to meet the requirements of the project and governing building codes. Coordinate with other specification sections and drawings. In no case shall these Guide Specifications be considered to be Contract Documents or serve as installation instructions for the product being discussed. In any cases of discrepancy the manufacturer's most recently published data sheet shall take precedent.

PART 1: GENERAL

{Note to Specifier: Insert the following paragraph and sub paragraphs as required for your project. Euclid's recommended products are shown in italics. More info can be found on these products at www.euclidchemical.com or by clicking on the product links.}

1.01 RELATED WORK:

- A. Joint Fillers Eucolastic, Tammsflex, Dural 340, Qwikjoint UVR
- B. Concrete Repair:
 - 1. Vertical and Overhead: <u>Euco V-100</u>, <u>Tamms Structural Mortar</u>
 - 2. Horizontal: Express Repair, VersaSpeed
 - 3. Form and Pour: Eucocrete
- C. Crack Repair/Injection: Dural 452 LV, Dural Fast Set Epoxy Gel
- D. Bonding Agents: Duralprep A.C., Dural 452 MV
- E. Waterproofing/Dampproofing: <u>Tamoseal</u>, <u>Vandex Super</u>, <u>Hey'Di K-11</u>, <u>Vandex BB75</u>
- F. Architectural Coatings: <u>Tammscoat</u>, Tammolastic
- G. Anti-Graffiti Coatings: AG 100, AG-400, Euco 563
- H. Traffic Deck Coatings: <u>Tammsdeck</u>, <u>Flexdeck</u>
- I. Decorative Floor Coatings: <u>Duraltex</u>
- J. Epoxy Chemical Resistant Coatings: <u>Duralkote 240</u>, <u>Duralkote 500</u>, <u>Duraltex 1705/07</u>, <u>Duraltex 1805/07</u>
- K. Penetrating Water Repellents:
 - 1. Horizontal and Vertical: <u>Baracade WB 244</u>, <u>Baracade 100C</u>, <u>Baracade Silane 40</u> <u>IPA</u>
 - 2. Vertical: Chemstop WB Regular/Heavy Duty
- L. Penetrating Epoxy Sealer: Euco #512 VOX Epoxy Sealer
- M. Cathodic Protection: Sentinel Galvanic Anodes

1.02 JOB SITE CONDITIONS

- A. Material shall be stored at temperatures between 40 and 90 deg F.
- B. Do not apply Penetrating Water Repellent Sealer to frost filled surfaces. Both substrate and ambient temps shall be 45 deg F. and rising at time of application.

- C. Do not apply Penetrating Water Repellent at temperatures above 90 deg F.
- C. Do not apply Penetrating Water Repellent Sealer if rain is expected within 12 hours.

PART 2.0 PRODUCT

2.01 PENETRATING WATER REPELLENT SEALER

- A. Penetrating Water Repellent: Water Based, ready to use, silane/siloxane blend, penetrating, clear water repellant sealer designed for use on porous masonry and concrete surfaces.
 - 1. Viscosity 50 cps
 - Reduction in Water Absorption SS-W-110C: 90.5%
 - 3. Accelerated weathering, 1500 hrs.: No change
 - 4. Abrasion resistance: Excellent
 - 5. VOC's 50 g/l
 - 6. Product:
 - a) Euclid Chemical Company (The): Chemstop WB Heavy Duty www.euclidchemical.com
- B. Manufacturer shall have ISO 9001 Quality Certification.

PART 3.0 EXECUTION

3.01 SURFACE PREPARATION

A. Surface shall be structurally sound, clean, dry, free of dust, dirt, paint, efflorescence, laitance and other contaminants that will prevent the proper penetration of penetrating water repellent. A dry substrate is required for proper penetration of the sealer. Prior to application, joints or cracks must be properly sealed. If acid is used for cleaning, neutralize completely before application of penetrating water repellent.

3.02 PENETRATING WATER REPELLENT APPLICATION:

- A. Apply [1][2] coat[s] per manufacturer's recommendations utilizing low pressure airless spray equipment.
 - 1. Actual coverage and number of coats to be determined by field test sample application and water absorption testing. Final approval by architect/engineer is required.
 - 2. Where a second coat is required it shall be applied "wet on wet" before the first coat dries.
- B. Do not allow material to puddle. Remove excess material with squeegee or broom.

END OF SECTION