



NOTE:

1. REFER TO THE DRILL-TEC™ RHINOBOND® PURLIN ATTACHED SYSTEMS TABLE FOR DETAILED INSTALLATION REQUIREMENTS.
2. REFER TO APPROPRIATE EVERGUARD® 100 SERIES LAP DETAIL.



**RIDGE FLASHING
- DRILL-TEC™ RHINOBOND® & PURLIN ATTACHMENT**

DRAWING #
110F

THIS DETAIL APPLIES TO:
RHINOBOND® SYSTEMS

ISSUE / REVISION DATE
8/17/20

SCALE
N.T.S.

LEGEND

~~~~~ HEAT-WELDED