



NOTE:

1. REMEMBER TO INSTALL EVERGUARD® UNREINFORCED OR PREMANUFACTURED OUTSIDE CORNERS TO THE SCUPPERS' FOUR ROOF-SIDE CORNERS.
2. OPTIONS 1 & 2 EITHER PREFABRICATED OR FIELD-FABRICATED.
3. DRILL-TEC™ PLATES & SCREWS REQUIRED FOR BASE ATTACHMENT 6" (152 mm) O.C. FOR BALLASTED SYSTEMS.
4. IF EVERGUARD® COATED METAL IS NOT AN OPTION ADHERE MEMBRANE TO THE NEW SCUPPER BOX.
5. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).



EverGuard
SINGLE-PLY ROOFING SYSTEMS
PARAPET WALL & CURB SERIES

DRAWING #

311

SCALE
N.T.S.

COATED METAL WALL SCUPPER DETAIL

THIS DETAIL APPLIES TO:
Adhered Systems
Ballasted Systems
Mechanically Attached Systems
Self-Adhered Systems
TriPosite Systems

REVISION DATE
6-23-15

www.gaf.com
1 Campus Drive,
Parsippany, NJ 07054