



NOTE:

1. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).



PARAPET WALL
& CURB SERIES

COUNTERFLASHING RE-ROOF DETAIL

DRAWING #

319

SYSTEM

MA/FA/BA

SCALE

N.T.S.

ISSUE/ REVISION DATE

6-01-10