



**NOTE:**

1. STONE/PAVER BALLAST (NOT SHOWN) REQUIRED FOR BA SYSTEMS.
2. INSTALL RETROFIT DRAIN INTO EXISTING DRAIN PER MANUFACTURERS RECOMENDATION.
3. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES ( REFER TO DETAIL MA/FA/BA 115 ).



ROOF PENETRATION SERIES

**DRAIN - RETROFIT/ INSERT**

DRAWING #

**516**

SCALE

N.T.S.

SYSTEM

**MA/FA/BA**

ISSUE/ REVISION DATE

9-01-09