



NOTE:

1. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO EVERGUARD® DETAIL 115).

EXTEND REINFORCED EVERGUARD® MEMBRANE ONTO MEMBRANE SECTION POSITIONED AT DRAIN SUMP AND CUT AS SHOWN TO LAY FLAT IN SUMP. HOT AIR WELD A MIN. OF 2" (52 mm) COMPLETELY SURROUNDING AREA.



EverGuard
SINGLE-PLY ROOFING SYSTEMS
ROOF PENETRATION SERIES

DRAWING #

518

DRAIN- SEVERE SUMP TARGET

THIS DETAIL APPLIES TO:
Adhered Systems
Ballasted Systems
Mechanically Attached Systems
TriPosite Systems

www.gaf.com
1 Campus Drive,
Parsippany, NJ 07054

SCALE
N.T.S.

REVISION DATE
5-26-16