



NOTE:

1. STONE/PAVER BALLAST (NOT SHOWN) REQUIRED FOR BA SYSTEMS.
2. DRAIN PIPE SHALL BE CLEANED SO THAT EXPANDING TAPE SEAL CAN SEAT COMPLETELY AGAINST DRAIN PIPE AFTER RELEASE PAPER HAS BEEN REMOVED.
3. EVERGUARD TPO DRAIN CAN ALSO BE USED AS A RETROFIT DRAIN.
4. APPLY EVERGUARD® TPO CUT EDGE SEALANT TO ALL CUT REINFORCED TPO EDGES (REFER TO DETAIL MA/FA/BA 115).



DRAIN - PREFABRICATED TPO DRAIN WITH FLANGE

DRAWING #
521
SCALE
N.T.S.

SYSTEM
MA/FA/BA
ISSUE/ REVISION DATE
11-01-09