



NOTE:

1. ADD BALLAST PER SPEC FOR BA SYSTEMS.
2. APPLY EVERGUARD® TPO AND PVC CUT EDGE SEALANT TO ALL CUT REINFORCED TPO AND PVC EDGES (REFER TO DETAIL MA/FA/BA 115).

COATED METAL TAPERED EDGE DETAIL



WWW.GAF.COM
1361 Alps Rd.
Wayne, NJ 07470

ROOF EDGE SERIES

DRAWING #

203

SCALE

N.T.S.

SYSTEM

MA/FA/BA

ISSUE/ REVISION DATE

7-01-11