

- 1. FOR MASONRY SURFACES, INSTALL ONE PLY OF LIBERTY™ BASE/PLY SHEET (BACKER PLY) AND ONE PLY OF LIBERTY™ CAP SHEET ADHERED IN PLACE OVER A PRIMED SUBSTRATE. FOR WOOD SUBSTRATES, INSTALL ONE PLY OF LIBERTY™ MA BASE SHEET (BACKER PLY) MECHANICALLY FASTENED IN PLACE WITH CAP NAILS CONTAINING A 1" (25.4 mm) INTEGRAL METAL HEAD, 8" (203 mm) O.C. ALONG THE TOP AND SIDE LAPS, AND 8" (203 mm) O.C. IN ALL DIRECTIONS IN THE FIELD OF SHEET FOLLOWED BY ONE PLY OF LIBERTY™ CAP SHEET ADHERED IN PLACE.
- 2. REFER TO LIBERTY™ FLASHING SPECIFICATIONS PART 9.
- 3. LIBERTY[™] FLASHING DETAILS FOR USE ON LIBERTY TROOFING SYSTEMS ONLY.

www.gaf.com 1 Campus Drive. Parsippany, NJ 07054	Liberty	WALL FLASHING DETAIL FOR WALL SUPPORTED DECK	DRAWING#	SYSTEM LIB
	WALL & CURB SERIES		SCALE N.T.S.	ISSUE/ REVISION DATE 1-4-17