



**NOTE:**

1. ADD EXTRA FASTENERS AT EAVE, RAKE AND RIDGE.
2. ADD ADDITIONAL SPACERS AS NEEDED.
3. SFS DEKFAST NAILBOARD FASTENER REQUIRED.

**LEGEND:**

	= WOOD SPACER BLOCK
	= FASTENER REQUIRED



www.gaf.com  
1 Campus Drive,  
Parsippany, NJ 07054

BRAND SERIES

**CORNELL**

REVISION DATE

10-1-15

SCALE

N.T.S

**130 MPH FASTENER PATTERN**

Recommended Fastener Pattern for Special Wind Uplift Conditions

DETAIL NUMBER

**110R**

SYSTEM

**THERMACAL®**