



NOTE:

AT PEAK INSERT EXTRA SPACER BLOCKS IF THERE IS NOT A SPACER BLOCK WITHIN 3" OF THE CUT. CUT FOAM AT ANGLE TO FIT TIGHT TOGETHER. FILL ANY GAPS WITH URETHANE SPRAY FOAM.



www.gaf.com
1 Campus Drive,
Parsippany, NJ 07054

BRAND SERIES

CORNELL

REVISION DATE

10-1-15

SCALE

N.T.S

RIDGE VENT DETAIL

DETAIL NUMBER

204R

SYSTEM

THERMACAL® 1