



* NOTE: For all applications, the butt joints of the WeatherBlocker™ Starter Shingle must be offset from the butt joints of the first course of shingles by 4" or more. For long eaves, a 10" (254 mm) piece of Weather Blocker™ Starter may need to be installed periodically to adjust the offset. The frequency of this adjustment will depend on the length of the shingle being installed.



www.gaf.com
1361 Alps Rd.
Wayne, NJ 07470

BRAND SERIES
Weather Blocker™
Starter Strip
Shingles

REVISION DATE

6-01-12

SCALE

N.T.S

WEATHER BLOCKER™ STARTER STRIP SHINGLE DETAIL (LESS THAN 6" EXPOSURE)

DETAIL NUMBER

04

DETAIL REFERENCE

SS-WB4