

CertainTeed AquaBead®

Drywall Corner

AquaBead® Drywall Corner

Easy-to-apply, water activated, self-adhesive drywall corner that won't blister, bubble or edge crack. Available in Outside 90° beaded and beadless nose, Bullnose and L-Trim.

- Water-activated adhesive provides a superior bond directly to drywall
- Has an easily paintable paper face that won't chip or crack and is scratch resistant
- Outside 90 has a specially engineered beaded nose to allow for filling to the outer edge to create the perfect corner
- L-Trim offers quick and clean finishing of exposed drywall edges and reveals for a perfect edge
- Outside 90 Trim, with beadless nose, for durable outside corners in less time



Quick and Easy

- Just spray on water, wait 20–30 seconds and press – no compound or spray adhesive required
- Can be coated in 30 minutes for quicker finishing
- Superior Bond – water-activated adhesive creates an exceptional bond to drywall
- Perforated holes allow joint compound to seal corner to wall permanently
- Robust paper-plastic-paper design withstands impacts and movement to prevent dents and edge cracking

Product Data

DESCRIPTION:	CERTAINTEED CODE:	CARTON CODE:	PACKAGE SIZE:
AquaBead Outside 90° - 8'	313724	10800805137249	50 Sticks/Carton
AquaBead Outside 90° - 9'	313723	10800805137232	50 Sticks/Carton
AquaBead Outside 90° - 10'	313725	10800805137256	50 Sticks/Carton
AquaBead Outside 90° - 12'	314144	10800805141444	50 Sticks/Carton
AquaBead Bullnose - 8'	313728	10800805137287	50 Sticks/Carton
AquaBead Bullnose - 9'	313727	10800805137270	50 Sticks/Carton
AquaBead Bullnose - 10'	313721	10800805137218	50 Sticks/Carton
AquaBead L-Trim 1/2" - 10'	313726	10800805137263	50 Sticks/Carton
AquaBead L-Trim 5/8" - 10'	315029	10800805150293	50 Sticks/Carton
AquaBead Outside 90° Trim - 8'	318617	10800805186179	50 Sticks/Carton
AquaBead Outside 90° Trim - 9'	318618	10800805186186	50 Sticks/Carton
AquaBead Outside 90° Trim - 10'	318619	10800805186193	50 Sticks/Carton
AquaBead Outside 90° Trim - 12'	318620	10800805186209	50 Sticks/Carton

Distributed by:



CertainTeed AquaBead®

Drywall Corner

Installation Instructions

CertainTeed AquaBead® is an easy-to-apply, water-activated, self-adhesive drywall corner that doesn't blister, bubble, dent or crack.


When installing drywall for 90° corners, hang Outside 90 as shown in Figure 1a. Ensure that the drywall at the corner does not overlap the joint compound as shown in Figure 1b.

When installing drywall for Bullnose corners, hang as shown in Figure 2a and 2b. Ensure that drywall at the corners do not touch creating an open area for the radius of the bead.



PREPARATION

- AquaBead can be cut to length using scissors, metal snips or a chop saw.



APPLICATION

- Place the wet, adhesive side of the AquaBead on the wall corner, aligning it tightly to the ceiling.

The beaded edge of the AquaBead should be squared with the centre of the corner. Make sure it is straight.

- Press the AquaBead firmly by hand or with a roller, making sure the flanges contact the drywall surface completely.
- **REPOSITIONING:** AquaBead can be removed, re-wetted and repositioned if the adhesive has not set.
- AquaBead adhesive will not stick to previously finished drywall surfaces. Use a spray adhesive or joint compound to adhere to previously finished surfaces.
- If an area has not properly bonded, it can be mechanically fastened with staples before coating.

IMPORTANT: Once the adhesive has set, the AquaBead will be permanently bonded to the drywall and cannot be repositioned.

TIP If you have exposed drywall edges, use L-Trim for a quick and clean finish.

Figure 1a




Figure 1b




Figure 2a






Figure 2b



- If preferred, Taping or Mid to Heavyweight All Purpose Joint Compounds can be used to adhere AquaBead. If using this method, ensure joint compound has thoroughly dried before applying a fill coat.

TIP Create a guide with a pencil or chalk line to get straight corners, especially on bulkheads and long runs.



FINISHING

- AquaBead corner can be filled after 30 minutes using All-Purpose or Finishing joint compound.
- Apply joint compound over the AquaBead using an 8"–10" taping knife, filling the holes. Allow compound to dry thoroughly.
- Skim over the AquaBead corner once more with joint compound using a 10"–12" finishing knife. Let dry, then sand and paint.

Shipped in water-resistant packaging. Store in a dry location. Protect from moisture.



ASK ABOUT ALL OF OUR OTHER CERTAINTEED® PRODUCTS AND SYSTEMS:

ROOFING • SIDING • TRIM • DECKING • RAILING • FENCE
GYPSUM • CEILINGS • INSULATION

www.certainteed.com <http://blog.certainteed.com>

CertainTeed Corporation
20 Moores Road
Malvern, PA 19355

Professional: 800-233-8990
Consumer: 800-782-8777

© 06-2010 CertainTeed Gypsum, Inc. Rev 06-2016
Printed in Canada on recycled paper. CTG-4019