

# Roll Stop

**No More Up and Down,  
Up and Down, Up and Down!**

**GSL2 Brake Kit attaches to BOTH  
ends of the scaffold**



Now you can lock and unlock a utility scaffold from the top.

Eliminate the time-consuming and tiring job of climbing up and down to unlock casters and move scaffolding.

- ▶ **Fits all utility scaffolds**
- ▶ **Can be used up to 5' platform heights**
- ▶ **2 brake units (4 casters) are used for each utility scaffold**



Roll Stop  
attaches easily  
to scaffold frame



Lever releases  
brakes while  
standing on  
platform

## Roll Stop Instructions:



- 1 Attach top cross bracket with the clamp mounting flange facing away from the scaffold ladder, locating the saddles with the welded pin into:
  - ▶ 3rd hole down from top of ladder on Indy/Perry Units (Approximately 58" from bottom of ladder)
  - ▶ 4th hole down from top of ladder on Snappy Units (Approximately 56-1/2" from bottom of ladder)

- 2 Slide pole thru the bottom cross bracket before attaching to ladder, then slide bracket (with flange facing away from scaffold ladder) between ladder rails and it will sit down onto the snap pins that are holding the casters on to the scaffold. Bracket will just sit in place.

- 3 With the red indicator cap towards the top of the pole, thread pole into the toggle lever so there is approximately 1/4" of thread still exposed.

- 4 Screw footpad into the bottom of the pole, do not tighten at this point.

- 5 With weight applied to platform, adjust the footpad so that when the toggle lever is down in the locked position, the bottom of the red indicator cap matches up with the groove on the pole.

- 6 Tighten lock nut to secure footpad in place.

- 7 Repeat for opposite ladder.



When installed correctly, each locking assembly is located on opposite corners of the scaffold.

**Warning:** Use only on clean and level floors. Make sure toggle lever is fully engaged. Follow OSHA standards for scaffold construction and use. Failure to use as directed could cause serious injury.

Both locking assemblies must be installed on opposite corners of the scaffold.

Each Roll Stop system comes with TWO locking assemblies.

- ▶ 2pcs – top cross bracket with toggle lever
- ▶ 2pcs – bottom cross bracket
- ▶ 2pcs – vertical poles
- ▶ 2pcs – footpad
- ▶ 4pcs – snap pin

