


Notes:

1. Detail shows 2 ply reinforced 790-11EV membrane installed over concrete deck.
2. Comply with appropriate codes for minimum vent height.
3. Refer to Henry 790-11EV Guide Specification for specific installation procedures.
4. Pipe must be fully grouted or cast in place to prevent movement.

 www.henry.com	790-11EV WATERPROOFING MEMBRANE	SCALE: N.T.S.
	TYPICAL VRA ROOF ASSEMBLY	10-20-10
PLUMBING VENT DETAIL	VR-13	