



Note:

1. Polyester reinforcement to extend min. 3" over vertical and horizontal surface at change of plane.
2. Set polyester reinforcement into a bed of wet CM100 and allow to cure.
3. Apply CM100 onto polyester reinforcement and onto intended areas of planter.
4. Allow CM100 to cure.
5. Protection course or drainage composite required over completed membrane application.



CM100 WATERPROOFING - SINGLE COAT SYSTEM

SCALE: N.T.S.

CONCRETE DECK

08-04-09

**PLANTER
DETAIL**

CM-SC03