









GeoLap[™] adhesive tape is a solution designed specifically for RhinoMat[®] and RhinoSkin[™] geomembrane applications

- Incorporating high-strength adhesive, extra width and thickness, GeoLap[™] tape is designed to be a smart choice for geomembrane patching, repair, and protection.
- Stable from -70° F to 200° F and VOC-free, GeoLap[™] is a durable, polymeric-faced all-purpose tape utilizing a proprietary butyl adhesive backing.
- Standard 100-foot length rolls with a 4-inch width make GeoLap[™] tape advantageous for secondary repairs, seam protection, pipe boot and penetration sealing, batten reinforcement, and other geomembrane adhesive needs.

- Easy-to-peel paper release liner allows for faster installation with professional-looking results.
- Designed for water retention and containment applications in conjunction with RhinoMat* and RhinoSkin* installations.
- Be sure to stick with caution once GeoLap™ adhesive tape is applied, it does not come off easily!

Contact your Owens Corning RhinoMat^{*} representative today to find out how to order GeoLap[™] tape with your next shipment of geomembrane material.





Contact your Sales Representative at:

Toll Free: 800.567.9727 | Email: RhinoMat@OwensCorning.com

OwensCorning.com/RhinoMat