



**JL INDUSTRIES**

**Installation Instructions – CGL  
Lexan® Cornerguards**

**STORAGE, HANDLING & ENVIRONMENTAL CONDITIONS:**

1. All materials shipped unassembled. Store vertically or on flat horizontal surface.
2. Begin installation only after finish construction has been completed and building interior has been within temperature range intended for continued use for at least 24 hours. Install vinyl components only after they have been at temperature intended for continued use for 24 hours.

**INSTALLATION:**

Make sure the wall where corner guards are to be attached is smooth and clean so the corner guard will fit tight against the corner. Any surface defects will show through the clear lexan corner guards.

1. Place the corner guard in position. Attach with screws or brads provided.
2. Remove protective covering from corner guards and clean as necessary