


# INSTALLATION & MAINTENANCE INSTRUCTIONS: CGVA CORNER GUARDS

1. Warning: Surface Adhered Corner Guards, particularly adhesive-backed models, may not adhere properly at installation due to a variety of field conditions beyond our control. JL accepts no liability, nor expresses or implies any warranty regarding the effectiveness of the application/installation of these products. We recommend a trial installation to determine the general effectiveness of same, although adhesion problems with individual Corner Guards may still occur.
2. Locate and install Surface Adhered Corner Guard in accordance with architectural drawings and specifications.
3. Lay out work to be completed at the base of the substrate. Check the material for any damage that may have occurred during shipment and/or handling at job site.
4. Prior to installation, allow Corner Guards to reach room temperature. Inspect wall corners to confirm sound construction and repair if necessary. Thoroughly clean wall surfaces to assure proper Corner Guard adhesion. CAUTION: Other cleaning agents may damage certain types of wall finishes. Use the appropriate manufacturer-recommended cleaning agent and proceed with care.
5. If the wall surface is unusual in composition and/or texture or exhibits other characteristics that may jeopardize the effectiveness of the installation method, please contact Customer Service for assistance before proceeding with installation.
6. Dry-fit the Corner Guard to the wall corner to assure proper height and fit.
7. JL's Surface Adhered Corner Guards are provided in specified heights with or without factory-applied adhesive backing. If no adhesive has been provided, use only contact adhesive, Loctite PL 200 Construction Adhesive, or Liquid Nails Tub Surrounds & Shower Walls Adhesive and follow manufacturer's recommended procedures.
8. If adhesive-backed Corner Guards have been provided, carefully peel back and thoroughly remove the release liner from back of Corner Guard. Do not allow exposed adhesive to contact substances that will adhere and contaminate the adhesive surface.
9. Holding the Surface Adhered Corner Guard at an angle, carefully place and seat its bottom end against the corner at the proper location. Using care, fit the Corner Guard to the corner, progressing from bottom to top, applying pressure with fingers and palm to assure that it is seated precisely on the corner. If Corner Guards are full height, it is best that two people perform this operation. Note: Repositioning after contact is detrimental to the adhesive bond.
10. After placement, inspect the Corner Guard from top to bottom to confirm proper fit and surface contact. Using a high-pressure roller, firmly and thoroughly roll both wings of the Corner Guard to assure full and complete adhesion.
11. Wipe down installed Surface Adhered Corner Guard with soap and water to remove any dirt or grime. If there are any questions, please call Customer Service.



 <b>JL INDUSTRIES</b>	Distributor:	Quantity:
	Contractor:	Approved By:
	Model #:	Architect:
	Project:	Date: <small>© 2023 Activar Construction Products Inc</small>
<b>HEADQUARTERS:</b> 9702 NEWTON AVE S, BLOOMINGTON, MN 55431 <b>PH:</b> 800-554-6077 <b>EMAIL:</b> SALES@ACTIVARCPG.COM WWW.ACTIVARCPG.COM <b>MANUFACTURING:</b> BLOOMINGTON, MN & COMMERCE, CA <b>WAREHOUSES:</b> SEE WEBSITE FOR LOCATIONS 2/23/2023		

## General Information—Maintenance

JL's vinyl corner guards will retain their original beauty with reasonable handling and care. To ensure that your wallcovering maintains its original appearance, please review the following guidelines.

To clean, dust it with a soft, damp cloth or chamois and wipe the surface gently. Use soap and lukewarm water to remove light dirt. After washing and rinsing, be sure to dry the surface by blotting with a damp cloth or chamois to prevent streaking and water spots.

### For general (routine) cleaning, the following mild detergents and multi-purpose cleaners are recommended:

Joy®	Fantastik®
Janitor in a Drum	Formula 409®
Cascade®	Isopropyl alcohol
all® Detergent (powder)	SoftScrub®

Normal cleaning methods may not remove ground in dirt or grease. To remove dirt or grease from texture valleys, a short stiff bristled brush should be used to loosen the material followed by a water rinse.

### Cleaners Not Recommended:

Wisk®	Meguiar's® Carpet & Upholstery Cleaner	Isopar™ K
Persil® ProClean®	Abrasives	Pine-Sol®
Gasoline	Dynamo	Endust®
Tetrahydrofuran	Kerosene	Hexane
Lestoil®	Methanol	Goof Off "Works The 1st Time!"*
all® Detergent (liquid)	Ketones	
Brake Fluid	Cold Power® Liquid	

*\*Note: The chemical composition of Goof Off has been reformulated. This updated formulation has been observed to have an affect on Korogard sheet. The previous formulation may be identified by the phrase "The Professional Cleaner" on the can and is produced by Valspar®. This formulation is still recommended for use on Korogard sheet. The updated formulation may be identified by the phrase "Works The 1st Time!" on the can and is produced by W.M. Barr & Co. Korogard is investigating suitable alternatives to the Goof Off product.*

### In-Use Spot Cleaning

Tough marks or stains due to spills, graffiti, heel marks, etc., usually require cleaners such as DWR-II®, Zep® Write Away, and Valspar® Goof Off to provide good results when trying to remove graffiti marks. These are specialized spot cleaners that should be used for small areas only. A short, stiff, bristled brush may be necessary to remove some stains from the textured surface. These cleaners should also be rinsed thoroughly with clean water. Some heel marks or abrasions from rubber bumpers on carts may be removed simply by brushing without a cleaner.