


**NOTES:**

1. BOTH SURFACES TO BE MATED MUST BE CLEANED WITH JM TAPE PRIMER/WASH. THE JM TAPE PRIMER/WASH MUST BE COMPLETELY DRY AND TACK FREE BEFORE LAP CEMENT APPLICATION.
2. USE T-JOINT PATCH OR 6" (150 mm) WIDTH JM PEEL & STICK SEALING STRIP OVER FIELD SEAM AT CHANGE OF ANGLE.
3. KEEP RTS 6" (150 mm) TO 9" (225 mm) FROM INSIDE CORNERS.

DRAWING NO.  <b>EB-3</b>	<b>BASE FLASHING WITH JM EPDM MEMBRANE AS FLASHING AND JM EPDM REINFORCED TERMINATION STRIP (RTS) FASTENED TO WALL</b>			 <b>Johns Manville</b>
	SCALE N.T.S.	ISSUE DATE 3-06	CAD SP03BFW	