


NOTES:

1. PREFABRICATED CORNERS AND HORIZONTAL-TO-VERTICAL TRANSITIONS ARE AVAILABLE TO COMPLETE THE EXPAND-O-FLASH INSTALLATION.
2. THE JM TAPE PRIMER/WASH MUST BE COMPLETELY DRY AND TACK FREE BEFORE LAP CEMENT APPLICATION.

DRAWING NO. EJ-3	EJ EXPAND-O-FLASH® ROOF EXPANSION JOINT COVER (ROOF-TO-ROOF)			 Johns Manville
	SCALE N.T.S.	ISSUE DATE 3-06	CAD SP03C2C	