


**NOTES:**

1. PREFABRICATED CORNERS AND HORIZONTAL-TO-VERTICAL TRANSITIONS ARE AVAILABLE TO COMPLETE THE EXPAND-O-FLASH INSTALLATION.
2. THE JM TAPE PRIMER/WASH MUST BE COMPLETELY DRY AND TACK FREE BEFORE LAP CEMENT APPLICATION.

DRAWING NO. <b>EJ-4</b>	<b>EXPAND-O-FLASH® ROOF EXPANSION JOINT COVER (ROOF-TO-WALL)</b>			 <b>Johns Manville</b>
	SCALE N.T.S.	ISSUE DATE 3-06	CAD SP04R2W	