


- NOTES:
1. CLEAN AND PRIME MEMBRANE IN LAP AREAS WITH JM TAPE PRIMER/WASH. THE JM TAPE PRIMER/WASH MUST BE COMPLETELY DRY AND TACK FREE BEFORE LAP CEMENT APPLICATION.
 2. DETAIL AS SHOWN LIMITED TO FM GLOBAL 1-90.

DRAWING NO. EE-2	JM PRESTO LOCK® FASCIA SYSTEM			
	SCALE N.T.S.	ISSUE DATE 3-06	CAD SP02PTO	