



NOTES:

1. WHEN TAPE EXPOSURE IS LESS THAN 0" (0 mm), TOP MEMBRANE SHOULD BE TRIMMED FLUSH WITH TAPE EDGE.
2. BOTH SURFACES TO BE MATED MUST BE CLEANED (WHEN REQUIRED) WITH JM EPDM TAPE PRIMER/WASH.
3. T-JOINT PATCH MUST BE USED ON MEMBRANE WHERE JM SEAM TAPE OVERLAPS.

DRAWING NO. EL-1T	LAP SPLICE WITH SEAM TAPE			 Johns Manville
	SCALE N.T.S.	ISSUE DATE 3-06	CAD SP01LAP2	