


NOTE:
 WHEN USING JM EPDM SEAM TAPE STRIPS, WIPE MEMBRANE CLEAN WITH DRY CLOTH (DO NOT PRIME MEMBRANE) PRIOR TO APPLYING STRIPS TO MEMBRANE.

DRAWING NO. EM-11	LIGHTNING ROD ON MEMBRANE SURFACE			
	SCALE N.T.S.	ISSUE DATE 3-06	CAD SP11MIS	