


NOTE:
 DETAIL SHOWN FOR WALL FLASHING APPLIED FIRST. ALTERNATE DETAIL IS TO INSTALL METAL SLEEVE FIRST AND STRIP-IN TO PARAPET WALL, THEN FLASH OVER ENTIRE PARAPET WALL. THIS ALTERNATE WOULD RESULT IN FEWER EXPOSED CAULKED SEAMS.

DRAWING NO. EM-8	OVERFLOW SCUPPER WITH METAL SLEEVE			
	SCALE N.T.S.	ISSUE DATE 3-06	CAD SP08MIS	