



NOTE:
 DETAIL SHOWN FOR WALL FLASHING APPLIED FIRST. ALTERNATE DETAIL IS TO INSTALL METAL SLEEVE FIRST AND STRIP IN TO PARAPET WALL, THEN FLASH OVER ENTIRE PARAPET WALL. THIS ALTERNATE WOULD RESULT IN FEWER EXPOSED CAULKED SEAMS.

DRAWING NO. EM-9	PRIMARY DRAIN SCUPPER WITH THROUGH WALL METAL SLEEVE			 Johns Manville
	SCALE N.T.S.	ISSUE DATE 3-06	CAD SP09MIS	