

JAMB OR POST, EXTEND "CRC"
INTO PUNCH-OUT. ATTACH "CRC"
TO JAMB OR POST WITH "BRC" WITH
SCREWS @ PRE-DRILLED HOLES

NOTE: CRC BRACING FOR 3%" TO 8" STUDS ONLY!!

CRC LATERIAL BRACING

Marino\WARE

4. CURTAINWALL DETAIL