


Drive Rivet hole location

Pre-drill 9/32" hole, which is slightly over-sized to allow for panel expansion. Remove any excess debris or dust from hole. Insert rivet snug to panel face. Lightly tap in pin head using a flat-faced hammer. This will cause the Pin Body to expand. Stagger fastening points on adjacent panels. Typically 28-32 fasteners per panel.

 330.343.6621 - PHONE 330.343.4731 - FAX drawings@marlite.com	Product Line: DRIVE RIVET INSTALLATION			Sheet: A-1	Drawing Number: 120203DRI
	Date: 12.02.03	Revision:	Drawn By: TJR	Approved By:	1 OF 1