



INSTALLATION DESIGN CONSIDERATIONS

- Locate insulation horizontally between wall ties directly on back-up wall.
- Provide 1” minimum clear space between inside brick face and the exterior surface of the insulation board.
- Abut foam insulation board joints tightly. Cut insulation to fit tightly around vents, louvers, pipes, conduits and other through-wall/insulation penetrations.
- Joints and openings should be sealed with Owens Corning Bild-R-Tape.
- Provide adequate flashings, functioning weepholes and caulk movement joints.
- The need for and placement of vapor retarders should be determined by the building designer.
- Architect must supply detailed drawings to meet project and building code requirements.



PRODUCT OPTIONS

- ▶ 700 Series Insulation
- ▶ Curtainwall Insulation/CW225

© 1996 – 2002 by
Owens Corning