



**INSTALLATION DESIGN CONSIDERATIONS**

- Foamular 150 or 250 should be used for residential and light commercial applications where floors are subject to normal loads.
- Use Foamular 400, 600, or 1000 for industrial applications where floor areas will be exposed to heavy loads.
- Utilize gravel fill to establish a stable, even base. Gravel must be thoroughly tamped before installing insulation.
- Butt insulation boards tightly together and against foundation walls or adjacent vertical insulation.
- The need for and placement of vapor retarders should be determined by the building designer.
- See product compressive strength on product datasheets to determine product requirements.



**PRODUCT OPTIONS**

- ▶ Foamular 150/250
- ▶ Foamular 400/600/1000

© 1996 – 2002 by  
Owens Corning