



**INSTALLATION DESIGN CONSIDERATIONS**

- Maximum wood stud spacing 24” o.c., 16” o.c. for fire resistance rated assemblies.
- Provide adequate lateral bracing for structural framing. Foamular insulation is not a structural material.
- Fit insulation board joints tightly and tape with Owens Corning Bild-R-Tape.
- Install siding materials according to the manufacturer’s recommendations.
- Wood siding products; install per “Guidelines for Installing Wood and Hardboard Siding over Rigid Foam Sheathing.” For more information contact Owens Corning.
- Shingle or vertical siding applications; attach horizontal wood nailing strips through insulation to studs. Nail shingles or siding to strips.
- Provide adequate flashings and caulk movements joints.
- The need for and placement of vapor retarders should be determined by the building designer.
- Architect must supply detailed drawings to meet project and building code requirements.



**PRODUCT OPTIONS**

- ▶ Foamular 150/250
- ▶ Insulating Sheathing
- ▶ ProPink
- ▶ Thermal Batt Insulation

© 1996 – 2002 by  
Owens Corning