



# GEO LAP<sup>™</sup>

ADHESIVE TAPE



## GeoLap<sup>™</sup> adhesive tape is a solution designed specifically for RhinoMat<sup>®</sup> and RhinoSkin<sup>™</sup> geomembrane applications

- Incorporating high-strength adhesive, extra width and thickness, GeoLap<sup>™</sup> tape is designed to be a smart choice for geomembrane patching, repair, and protection.
- Stable from -70° F to 200° F and VOC-free, GeoLap<sup>™</sup> is a durable, polymeric-faced all-purpose tape utilizing a proprietary butyl adhesive backing.
- Standard 100-foot length rolls with a 4-inch width make GeoLap<sup>™</sup> tape advantageous for secondary repairs, seam protection, pipe boot and penetration sealing, batten reinforcement, and other geomembrane adhesive needs.
- Easy-to-peel paper release liner allows for faster installation with professional-looking results.
- Designed for water retention and containment applications in conjunction with RhinoMat<sup>®</sup> and RhinoSkin<sup>®</sup> installations.
- Be sure to stick with caution - once GeoLap<sup>™</sup> adhesive tape is applied, it does not come off easily!

*Contact your Owens Corning RhinoMat<sup>®</sup> representative today to find out how to order GeoLap<sup>™</sup> tape with your next shipment of geomembrane material.*



Contact your Sales Representative at:  
Toll Free: 800.567.9727 | Email: [RhinoMat@OwensCorning.com](mailto:RhinoMat@OwensCorning.com)  
[OwensCorning.com/RhinoMat](http://OwensCorning.com/RhinoMat)

©2017 Owens Corning. All Rights Reserved