

## STEP 1

Place bollard base on leveled subgrade at location and orientation indicated on shop drawings.

---

## STEP 2

Check that top surface of bollard base is level and at correct top of slab elevation. Make adjustments with wedges and removal of subgrade as necessary

---

## STEP 3

Place and finish concrete.

---

## STEP 4

Use internal vibration to consolidate concrete around the bollard base per industry guides for embedments.

---

## STEP 5

Finish to edge of plate.

---

## STEP 6

Remove paste from top of bollard base plate.

---

## STEP 7

Install bollard with type and size of weld indicated on shop drawings.

---

