



CEMENT & CONCRETE PRODUCTS™

BLACKTOP PATCH

PRODUCT NO. 1701-60

DIVISION 32

Flexible Pavement Repair
32 01 17

PRODUCT DESCRIPTION

QUIKRETE® Blacktop Patch is a cold asphalt mix consisting of sand, stone and asphalt. It requires no heating and no mixing and is used right out of the bag.

PRODUCT USE

QUIKRETE® Blacktop Patch instantly repairs chunk holes in asphalt or concrete surfaces. Typical applications include:

- Driveways
- Patios
- Walks
- Filling in around drains

SIZES

- QUIKRETE® Blacktop Patch – 60 lb (27.2 kg) bags

YIELD

- Each 60 lb (27.2 kg) bag of QUIKRETE® Blacktop Patch will yield approximately 0.6 ft³ (17 L) when properly compacted and will cover an area of approximately 7.2 ft² (0.67 m²) when placed at a thickness of 1 in (25 mm).

INSTALLATION

SURFACE PREPARATION

Square cut the vertical sides of the hole to provide for proper confinement of the patch. Remove all loose material. Sweep the area thoroughly. Sweep area to be filled and remove all loose material. For best results, clean with QUIKRETE® Concrete & Asphalt Cleaner (No. 8601). Rinse thoroughly with clean water, and then remove standing water (not required). Performance is further improved if surface is dry.

APPLICATION

- Fill the hole with QUIKRETE® Blacktop Patch to a height of ½ in (13 mm) above the surrounding area. Do not apply less than 1 in (25 mm) thick. Material over 1 in (25 mm) must be applied in 1 in (25 mm) lifts which must be adequately compacted before additional material is added.
- Compact to a level surface with a tamper. (The repair may be covered with plywood or plastic then driven on with the front wheel of a car to further compact the repaired area. The plywood or plastic will then need to be removed, or it may impede the curing process.)
- Traffic can begin immediately after satisfactorily leveling and compacting.



PRECAUTIONS

- Apply QUIKRETE® Blacktop Patch at a depth of 1 in – 3 in (25 - 75 mm). Apply in 1 in (25 mm) lifts so that adequate compaction of each layer can be accomplished before more material is added. The product is not designed for curbs or other unconfined areas. Restrict the size of the repair to an area of approximately 3 ft × 3 ft (0.9 m × 0.9 m).
- Avoid getting QUIKRETE® Blacktop Patch on hands or clothing.
- Avoid dry turning tires on patched area until the material has hardened sufficiently (certain weather conditions may extend this period).
- Allow repaired area to cure for a minimum of 30 days (preferably 90 days or more) before applying driveway sealer.

QUICK TIPS

- QUIKRETE® Blacktop Patch can be driven over immediately. The more the product is driven over, the faster it will harden.
- QUIKRETE® Blacktop Patch will continue to harden as it ages.
- Spreading a small amount of fine, dry sand over the repaired area prior to final compaction can help reduce the curing time of QUIKRETE® Blacktop Patch. This will affect the appearance. Water is no problem for QUIKRETE® Blacktop Patch. Apply per instructions and the water will be displaced.

*Refer to www.quikrete.com for the most current technical data, SDS, and guide specifications

WARRANTY

The QUIKRETE® Companies, LLC warrant this product to be of merchantable quality when used or applied in accordance with the instructions herein. The product is not warranted as suitable for any purpose or use other than the general purpose for which it is intended. Liability under this warranty is limited to the replacement of its product (as purchased) if found to be defective, or at the shipping companies' option, to refund the purchase price. In the event of a claim under this warranty, notice must be given to The QUIKRETE® Companies, LLC in writing at:

The QUIKRETE® Companies, LLC
One Securities Centre
3490 Piedmont Rd., NE, Suite 1300, Atlanta, GA 30305

THIS WARRANTY IS ISSUED AND ACCEPTED IN LIEU OF ALL OTHER EXPRESS WARRANTIES AND EXPRESSLY EXCLUDES LIABILITY FOR CONSEQUENTIAL DAMAGES.